

POV INSPECTION CHECKLIST

ITEM	WHAT TO CHECK	LOOK FOR KNOWN DEFICIENCIES	CHECK OFF	
TIRES	Condition <i>NOTE: No mixing of radial tires and bias tires.</i>	Tread depth, wear, weathering, evenly seated, bulges, imbedded objects, cuts, breaks. At least one mm of tread over entire traction surface. <i>(Using a penny, place it in the tire tread with head facing downward. If the tread does not reach the top of Lincoln's head, there is insufficient tread depth)</i>	Front	Rear
	Spare tire	Spare tire (inflated), jack, lug wrench	Pass	Fail
LIGHTS	Head lights	Both high and low beams operational, cracked, condensation, secured	Left	Right
	Tail Lights	Lenses intact, tail light working when turned on (red)	Left	Right
	Brake lights	Lenses intact, brake light working when brake is applied (red)	Left	Right
	Turn Signals	Lenses intact, left and right turn signals blink (red lights in rear and yellow lights in front)	Front Left	Rear Right
	Backup lights	Lenses intact, left and right backup lights work (White Light)	Left	Right
	Four-way Flashers	Lenses intact, left and right turn signals flash/blink at the same time	Front Left	Rear Right
	License Plate Light	Lenses intact, does light stay on	Pass	Fail
WINDSHIELD & WINDOWS & WIPERS	Windshield	Not cracked, broken or scratched to the degree that impairs vision	Pass	Fail
	Rear Window	Not cracked, broken or scratched to the degree that impairs vision	Pass	Fail
	Windows	Windows go up and down, scratched or tinted to the degree that impairs vision	Pass	Fail
	Window controls	Check handles, push electric buttons	Front	Rear
	Windshield wipers	Both wipers are installed on vehicle, windshield wipers work, blades show signs of wear	Pass	Fail
MIRROR	Mirror Outside	Missing, cracked, adjustable	Left	Right
	Mirror Inside	Missing, cracked, adjustable	Pass	Fail
BUMPERS	Bumper Front	Missing, loose, broken	Pass	Fail
	Bumper Rear	Missing, loose, broken, bent in any way to cause a hazard	Pass	Fail
BRAKES	Brakes	Foot pedal cannot travel more than half way to floor, does brake light stay on	Pass	Fail
	Emergency Brake	Properly adjusted, check emergency brake by: pull/push emergency brake, apply foot to brake, gently press gas pedal, ensure brake holds vehicle	Pass	Fail
Interior	Horn	Does it work	Pass	Fail
	Defroster Front	Ensure hot air blows out above the dash	Pass	Fail

Defroster Rear	Check light on dash, if in the winter ensure it works by allowing the rear windshield to clear up	Pass	Fail
Emergency equipment	(OPTIONAL) First aid kit, warning triangle, flashlight, fire extinguisher, blanket, flares, shovel, chains, tools, etc.	Pass	Fail
Heater	Ensure heater works	Pass	Fail
SEATBELTS Seatbelt Front/Rear (Include shoulder harness during inspection, may have a center seat belt)	Missing, frayed, does not snap	Front	Rear
LICENSE/DECALS/INSURANCE State Drivers License	Expired, missing	Pass	Fail
License Plate/ Inspection Decal	Expired, check sticker/decal to ensure plate is current	Pass	Fail
Insurance	Does the operator have valid insurance	Pass	Fail
UNDER THE HOOD FLUIDS Brake	Filled to appropriate level	Pass	Fail
Windshield washer	Windshield washer fluid	Pass	Fail
Oil	Filled to appropriate level	Pass	Fail
Power Steering	Filled to appropriate level	Pass	Fail
HOSES	Cuts, cracks, leaks, bulges, chaffing, deterioration	Pass	Fail
BATTERY	Terminals, clean and tight, held down securely	Pass	Fail

Inspector's

Name: _____ Signature _____

Operator

Name: _____ Signature _____

Platoon Sergeant/Platoon Leaders

approval _____

Date inspection was conducted _____

Date follow-up inspection was conducted _____

Leave/Pass/Holiday _____